

Moisturizing Eye Cream

CC-E0006

Procedure:

1. Add warm (~40°C) deionized water to mixing vessel. Dissolve Disodium EDTA into the water.
2. Disperse **Carbopol®* Ultrez 10 Polymer** by sprinkling on the surface of warm deionized water. After polymer has wetted, mix slowly for 10 minutes.
3. Add ingredients in PART B in the order shown to PART A, ensuring that each is completely dissolved before the addition of the next ingredient.
4. In a separate vessel, combine ingredients in PART C and mix until homogenous.
5. Add PART C to the batch and continue mixing.
6. Slowly add **Acacia Collagen / 97** in PART D to batch and mix until homogenous.
7. In a separate vessel, combine ingredients in Part E and mix completely.
8. Add PART E to the batch and mix until homogenous.
9. Slowly add **Novemer®* EC-1 Polymer** in PART F and mix until homogenous.