

Light W/O Lotion

F 56/04-6

	%
A	
ISOLAN® GPS	3.00
Polyglyceryl-4 Diisostearate Polyhydroxystearate Sebacate	
TEGOSOFT® DEC	7.00
Diethylhexyl Carbonate	
Cyclopentasiloxane	10.80
Hydrogenated Castor Oil	0.10
Paracera W 80	0.10
Microcrystalline Wax, Paramelt B.V.	
B	
Water	75.50
Glycerin	2.00
Magnesium Sulfate Heptahydrate	1.50
Z	
Preservative, Parfum	q.s.

Preparation:

1. Heat phase A to approx. 80 °C.
2. Add phase B (80 °C or room temperature) slowly while stirring.
3. Homogenise for a short time.
4. Cool with gentle stirring below 30 °C and homogenise again.

Goldschmidt GmbH
Goldschmidtstrasse 100 | D-45127 Essen / Germany | P.O. Box D-45116 Essen
Phone: +49 (201) 173 - 2854 | Fax: +49 (201) 173 - 1828
personal-care@degussa.com | www.degussa-personal-care.com

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express

or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used. (Status: May 2003)