

## Quick Breaking W/O Emulsion

PW W0 90-2

	%
<b>A</b>	
<b>ABIL® EM 90</b>	0.80
Cetyl PEG/PPG-10/1 Dimethicone	
<b>ABIL® Wax 9801</b>	1.60
Cetyl Dimethicone	
<b>TEGOSOFT® DEC</b>	2.00
Diethylhexyl Carbonate	
<b>ABIL® 350</b>	1.00
Dimethicone	
Cyclomethicone	4.00
Magnesium Stearate	0.30
<b>B</b>	
Water	84.30
Propylene Glycol	5.00
Sodium Chloride	1.00
<b>Z</b>	
Preservative	q.s.

### Preparation:

1. Intensively disperse magnesium stearate into oil phase (Ultra-Turrax 25.000 rpm, 1 Min.) at room temperature.
2. Add water phase at room temperature slowly while stirring.\*
3. Homogenize for 2 minutes at 1100 rpm.

### Remarks:

Stirrer: MFR

\* Agitation 200 rpm, incorporation time 20 minutes for a 200g batch.

Viscosity: ~ 70 Pas  
(r.t.; Brookfield RVT, Spindle C / 10 rpm)

Goldschmidt GmbH  
Goldschmidtstrasse 100 | D-45127 Essen / Germany | P.O. Box D-45116 Essen  
Phone: +49 (201) 173 - 2854 | Fax: +49 (201) 173 - 1828  
personal-care@degussa.com | www.degussa-personal-care.com

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express

or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used. (Status: May 2003)