

Night eye serum with Folic acid

Cell activator serum gel with regenerating and protective benefits from Folic Acid

Phase	Ingredients	INCI Name	% w / w	Supplier
A	Carbopol Ultrez 21	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	0.50	100435
	Water dem.	Aqua	88.00	
	Potassium Hydroxide 30% sol.	Potassium Hydroxide	1.10	100289
	Neolone 950 Preservative	Methylisothiazolinone	0.20	
B	Water dem.	Aqua	10.00	100288
	Potassium Hydroxide 30% sol.	Potassium Hydroxide	0.10	
	Folic Acid	Folic Acid	0.10	

Procedure

- 1 Add Carbopol to the water and wait until part A swells and start to form a gel
- 2 Add carefully part B to part A

Technical Data

pH: 6.8

Viscosity: 34100 cps (Brookfield, RV6, 10 rpm)

Supplier

100288 DSM Nutritional Products
 100289 Rohm and Haas Deutschland GmbH
 100435 Lubrizol Advanced Materials,In

100147-047/001



Additional Information: COSSMA , issue 5/ 2008, page 12

<http://www.cossma.com>
<http://www.cossma.ru/10>
<http://www.cossma.fr>
<http://www.cossma.es>