## Formulation Example Rahmenrezeptur

## High SPF Sunscreen Sustainable touched with RonaCare<sup>®</sup> Luremin MDA-S-41-07

	Ingredients	Art. No	).	INCI	[%]
А	Eusolex <sup>®</sup> T-S	1.05334	(1)	TITANIUM DIOXIDE, ALUMINA, STEARIC ACID	17.00
	Arlacel 1689 V		(2)	SORBITAN OLEATE, POLYGLYCERYL-3 POLYRICINOLEATE	6.00
	Sesame oil, bio		(3)	SESAMUM INDICUM	4.00
	Cetiol OE		(4)	DICAPRYLYL ETHER	12.00
	Dermofeel PR		(5)	POLYGLYCERYL-3 POLYRICINOLEATE	3.00
	Miglyol 812		(6)	CAPRYLIC/CAPRIC TRIGLYCERIDE	10.00
	Eutanol G		(4)	OCTYLDODECANOL	4.00
	Magnesium Stearate	1.00663	(1)	MAGNESIUM STEARATE	0.70
	all-rac-alpha-Tocopherol	5.00949	(1)	TOCOPHEROL	0.50
	Candelilla Wax		(7)	CANDELILLA CERA (CANDELILLA WAX)	1.00
В	RonaCare <sup>®</sup> Ectoin	1.30200	(1)	ECTOIN	0.50
	RonaCare <sup>®</sup> Magnesium Sulfate	1.60628	(1)	MAGNESIUM SULFATE	0.70
	Glycerol, anhydrous	1.04093	(1)	GLYCERIN	5.00
	Water, demineralized			AQUA (WATER)	27.50
С	RonaCare <sup>®</sup> Luremin™	1.30204	(1)	SORBITOL, DIHYDROXYMETHYLCHROMONE	1.00
	Water, demineralized			AQUA (WATER)	2.00
	Ethanol 96%	1.00971	(1)	ALCOHOL	5.00
	Salicylic Acid	1.00631	(1)	SALICYLIC ACID	0.10

**Procedure:** Phase A: Disperse T-S in the given emollients and emulsifiers (check dispersion grade via microscope), add magnesium stearate and wax and heat to 75 – 80°C. Heat phase B separately to 75°C. Add phase B slowly to phase A while stirring and homogenize. Disperse RonaCare<sup>®</sup> Luremin in the water of phase C. Add this mixture to A/B. Cool down while slowly stirring and add remaining ingredients of phase C at approx. 35°C. Cool down to room temperature while stirring.

Notes: Viscosity 25000 mPa s (Brookfield RV-DV II+, Helipath sp. B, 10 rpm), at 23°C

 $\rightarrow$  Broad spectrum UV protection performed by the mineral UV filter **Eusolex**<sup>®</sup> **T-S.** 

 $\rightarrow$  Retinol-like anti-aging properties provided by the nature-identical active **RonaCare<sup>®</sup> Luremin**.

 $\rightarrow$  Long-lasting moisturizing & soothing aspects realized with **RonaCare<sup>®</sup> Ectoin.** 

## Suppliers:

Suppliers.			
(1) Merck KGaA/Rona®	(2) Croda GmbH	(3) Gustav Heess GmbH	
(4) Cognis GmbH	(5) Dr. Straetmans	(6) Sasol Germany GmbH	(7) Ross Waxes

Merck provides information on application technologies and relevant regulations based upon our current knowledge and opinion at the time of printing. Merck makes no representation or warranty of any kind, express or implied, including merchantability or fitness for a particular use, with respect to such information or its application. Purchasers must independently determine the suitability of our ingredients for the purchaser's intended product, use or process. Purchaser is responsible for observing all laws and regulations relevant to such products, uses or processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to the intellectual property rights of third parties, and shall not be construed as any inducement to infringe the rights of third parties.

www.merck4cosmetics.com



