

Cosmetics

Baycusan® C 1010

Style & Care Hair Mousse

		% by wt.
Phase A	Aqua	81.25
	Sodium Stearoyl Glutamate	0.20
	Glycerin	0.10
	Aqua (and) Hydrolyzed Keratin	0.40
	Sorbitol	1.00
	Lauryl Glucoside	0.30
	Laureth-4	0.50
	Polyquaternium-39	2.50
	Panthenol	0.10
	Tocopherol-Acetate	0.10
	Methylpropanediol (and) Caprylyl Glycol (and) Phenylpropanol ¹⁾	1.50
	Amodimethicone	1.00
	Fragrance	0.05
	BAYCUSAN [®] C 1010	5.00
Phase B	Butane	3.00
	Propane	3.00
		100.00
Raw materials	1. Dermosoft [®] OMP, Dr. Straetmans	
Processing	Add all ingredients of phase A in a vessel under stirring, at RT. Transfer phase A in a pressure vessel. Inject under pressure phase B at RT to the pressure vessel.	

2016-01-18





Cosmetics

This information and our technical advice - whether verbal, in writing or by way of trials - are given in good faith but without warranty, and this also applies where proprietary rights of third parties are involved. Our advice does not release you from the obligation to check its validity and to test our products as to their suitability for the intended processes and uses. The application, use and processing of our products and the products manufactured by you on the basis of our technical advice are beyond our control and, therefore, entirely your own responsibility.

Our products are sold in accordance with the current version of our General Conditions of Sale and Delivery.

Published by: Coatings, Adhesives & Specialties Covestro AG 51373 Leverkusen, Germany www.cosmetics.covestro.com Contact: Sophie Viala Phone: +49 214 6009 4476

Page 2 of 2 Edition Replaces edition of

2016-01-18

