



Cosmetics

RR 8029

Baycusan® C 1005

Lipstick – Pearlescent Pink

	% by wt.
Phase A	
Hexyldecanol (and) Propylenglycol Dicaprylate/Dicaprate (and) Candelilla Cera (and) Hexyldecylaurat (and) Paraffinum Liquidum (and) Cera Microcristallina (and) C30-C50 Alcohol (and) Cera Alba (and) Buxus Chinensis (and) Carnauba (Copernicia Cerifera) (and) Polycyceryl-2 Dipolyhydroxystearat ¹⁾	71.90
Phase B	
Ricinus Communis (Castor) Seed Oil	6.40
Baycusan® C 1005	4.20
PEG-8 (and) Tocopherol (and) Ascorbyl Palmitate (and) Ascorbic Acid (and) Citric Acid	0.10
Mica ²⁾	2.50
Ethylhexylglycerin	0.40
CI 15850 (and) Ricinus Communis (Castor) Seed Oil ³⁾	0.30
CI 77491 (and) Ricinus Communis (Castor) Seed Oil ⁴⁾	0.70
Phase C	
Mica (and) Titanium Dioxide ⁵⁾	13.50
	100.00
Raw materials	
¹⁾ Kahlbase 6285 Luster Lipstick Base, Kahl	
²⁾ RonaFlair™ Silk Mica, Merck	
³⁾ Covapate Unired LC 3779, LCW-Sensient Cosmetic Technologies	
⁴⁾ Covapate Uniwhite LC 8780, LCW-Sensient Cosmetic Technologies	
⁵⁾ Timiron® Pearl Flake MP 10, Merck	



Cosmetics

RR 8029

Processing

In the main vessel add ingredients of phase (B) and heat to 90°C. In a side vessel add the ingredients of phase (A) and heat to 90°C until solids are melted. Add phase (A) to phase (B) while mixing and homogenize. Slowly add phase (C) to phase (A-B) while mixing. Pour sample at 90°C.

This information and our technical advice - whether verbal, in writing or by way of trials - are given in good faith but without warranty, and this also applies where proprietary rights of third parties are involved. Our advice does not release you from the obligation to check its validity and to test our products as to their suitability for the intended processes and uses. The application, use and processing of our products and the products manufactured by you on the basis of our technical advice are beyond our control and, therefore, entirely your own responsibility.

Our products are sold in accordance with the current version of our General Conditions of Sale and Delivery.

Published by: Coatings, Adhesives & Specialties
Covestro AG
51373 Leverkusen, Germany
www.cosmetics.covestro.com

Contact: Sophie Viala
Phone: +49 214 6009 4476